

Air Force Research Laboratory AFRL

Science and Technology for Tomorrow's Aerospace Forces

Success Story

1.3-MICRON DIODE-PUMPED SOLID-STATE LASER SYSTEM USED IN LASER RADAR RESEARCH



The Directed Energy Directorate's Solid State Laser Products Group inserted a 1.3-micron diode-pumped solid-state laser system into a Munitions Directorate ladar system. Munitions Directorate researchers will use this laser to test receiver performance and collect metrology data to determine optimal wavelengths for multi-wavelength operation. Multi-wavelength ladar is an active (illuminator) remote-sensing technique that will enable much greater ability to discern objects since objects have different reflection properties at different wavelengths.



Air Force Research Laboratory Wright-Patterson AFB OH

Accomplishment

The directorate developed and built a 1.3 micron diode-pumped laser system as part of an Air Force Office of Scientific Research effort to explore multi-wavelength laser radar. Directorate researchers are currently developing a second laser, operating at ~2.0 microns, in conjunction with the 1.3-micron system. This will allow Munitions Directorate researchers to explore the potential of such a multi-wavelength system for Air Force use.

Background

The laser is an end-pumped Nd:YVO4 laser that produces 1.1 watts average power at 1.342 microns with a beam quality of 1.2-1.3 at a Q-switching frequency of 20 KHz. The pump is a 15-watt Specification or Design Language 3460-P6 fiber-coupled diode array that directorate researchers packaged into a 19-inch rack mount box containing the associated electronics to digitally control the diode output power and temperature via keypad or RS-232 interface. The electronics include a diode current driver, an acoustic-optic Q-switch driver, thermo-electric cooler/controller, and a laser interlock system tied to the diode laser cooling.

Directed Energy Emerging Technologies

Additional information

To receive more information about this or other activities in the Air Force Research Laboratory, contact TECH CONNECT, AFRL/XPTT, (800) 203-6451 and you will be directed to the appropriate laboratory expert. (01-DE-16)